



ANEST IWATA Americas Fast Flow System Adaptor Chart

Use a #10 adaptor if you use

LS-400 Series 2 BASE
WS-400 Series 2 BASE
WS-400 Series 2 Clear
LS-400 SUPERNOVA ENTECH
WS-400 SUPERNOVA EVOTECH
Katana Plus
LPH-300
AIR Gunsa AZ3HTE-S IMPACT
Air Gunsa AZ3 HV-2
Air Gunsa AZ3HTE-2

Use a #12 adaptor if you use

LPH-400-LV
LPH-400-LVX
LPH-400-LVB
W-400-LV
W-400-LV-WBX
W-400

Use a #13 adaptor if you use

LPH-80